




(View from looking at the jersey)  
The MAC 88 patch should be placed off the left edge of NM Hockey crest; lined up with the right side of MAC 88 Patch and from bottom of patch, 1" above the silver/grey band.



Silver/grey Band